


# Whirlpool 4GWTW4740YQ0 03 - BASKET AND TUB PARTS

## BASKET AND TUB PARTS

For Model: 4GWTW4740YQ0  
(White)



W10469259

5

Whirlpool [Residential Whirlpool 4GWTW4740YQ0 Washer Parts](#) Parts Diagram 03 - BASKET AND TUB PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3352483</a>			Cap, Agitator
2	<a href="#">W10003790</a>			Screw And Washer
3	<a href="#">3949550</a>			Washer
4	<a href="#">63377</a>			Agitator
5	<a href="#">W10215108</a>			Ring, Tub
6	W10389330	<a href="#">W10349185</a>		Basket
7	<a href="#">21366</a>			Nut, Spanner
8	<a href="#">389140</a>			Tub Block, Basket Drive
9	<a href="#">W10339098</a>			Shield, Splash
10	W10238320	<a href="#">W10371566</a>		Tub-Outer
11	W10006371	<a href="#">W10324647</a>		Seal-Tub
12	<a href="#">W10215093</a>			Filter, Drain Pump
13	<a href="#">8533928</a>			Screw, 8-18 X 3/4
14	W10257088	<a href="#">W10349191</a>		Suspension
15	W10215136	<a href="#">W10440729</a>		Suspension
16	W10256551	<a href="#">W10440729</a>		Suspension

17	<a href="#">W10422641</a>		Harness, Lower
18	W10297436	<a href="#">353244</a>	Hose, Pressure Switch
19	<a href="#">W10005430</a>		Clamp, Pressure Hose Retainer
20	8533943	<a href="#">W10109200</a>	Screw, Baffle Mounting
21	<a href="#">W10298887</a>		Cable Tie
22	<a href="#">W10429200</a>		Retainer, Push In

