


Whirlpool 4PGSC9455JQ3 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Models: 4PGSC9455JQ3, 4PGSC9455JT3
(Designer White) (Biscuit)

AUTOMATIC
WASHER



3-06 Litho in U.S.A. (dtd)

1

Part No. 8181189

Whirlpool [Residential Whirlpool 4PGSC9455JQ3 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8316568		Not Available	Installation Instructions Use & Care Guide
"	8315981		Not Available	English/Korean
"	3954823		Not Available	Arabic
"	3954735		Not Available	Wiring Diagram
2	8271378			Top
"	8271380			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
"	3954357			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3357011	308685		Side Trim)
8	3356311			Screw And Washer, Lid Switch Shield
11	3949237	3949247		Switch-Lid

12	3976348		Absorber, Sound
13	3351355	W10119828	Screw, Lid Hinge Mounting
15	54584		Hinge, Lid
16	91770		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8316048	3957510	Lid
"	8316055	3957511	Lid
20	358684		Strike, Lid Switch
21	9724509		Bumper, Lid
22	3390631		Screw, 10-16 X 3/8
23	90016		Clip, Pressure Switch Hose
24	3362952		Dispenser, Bleach

the laundry company[®]

the laundry company[®]

the laundry company[®]