


# Whirlpool 4PLBR8543JQ2 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 4PLBR8543JQ2 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	<a href="#">16123</a>		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	285750		Not Available	(Kit-Adapter) (Includes. Item) (20. And 27.)
3	8571377	<a href="#">89503</a>		Hose-Inlet
"	8571378	<a href="#">89503</a>		Hose-Inlet
4	<a href="#">9740848</a>			Screw, Mixing Valve Mounting
5	<a href="#">8568314</a>			Strap, Console
6	<a href="#">3357976</a>			Panel, Rear
7	<a href="#">62747</a>			Pad, Rear Panel
8	3951609	<a href="#">285664</a>		Hose
"	661577	<a href="#">285666</a>		Hose
"	3357090	<a href="#">285702</a>		Hose
9	<a href="#">3954731</a>			Timer, Control
10	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting

11	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
12	3366848	<a href="#">W10339229</a>	Switch-WL
13	<a href="#">3948814</a>		Bracket, Control
14	<a href="#">3353850</a>		Cord, Power
15	3952821	<a href="#">285777</a>	Relief-Str
16	8271365	<a href="#">279962</a>	Endcap
"	8271368	<a href="#">279965</a>	Endcap
17	<a href="#">356138</a>		Clamp, Hose
18	3952165	<a href="#">285874</a>	Valve
19	<a href="#">3976395</a>		Restraint, Hose
20	<a href="#">3952439</a>		Buzzer, Mini
21	301958	<a href="#">596669</a>	Clamp, Manifold
22	8541607	<a href="#">3357328</a>	Hose, Vacuum Break
23	370450	<a href="#">596669</a>	Clamp, Manifold
24	<a href="#">3347034</a>		Break, Vacuum
25	<a href="#">3349557</a>		Retainer, Harness
26	3363920	<a href="#">3363920A</a>	Adapter
27	3366912	<a href="#">356138</a>	Clamp, Hose
30	3363366	<a href="#">616099</a>	Clamp
31	8317496	<a href="#">285655</a>	Clamp, Hose
32	3951449	<a href="#">285871</a>	Hose
33	<a href="#">3352944</a>		Clip, Harness
34	303294	<a href="#">3367669</a>	Protector, Edge
35	<a href="#">661614</a>		Switch, Water Temperature
36	<a href="#">3400818</a>		Screw, Timer Mounting
37	3949180	<a href="#">W10168257</a>	Switch, Rotary
39	<a href="#">8318784</a>		Panel, Console
"	<a href="#">8318794</a>		Panel, Console
41	357572	<a href="#">W10113937</a>	Clip, Grounding
42	3398893	<a href="#">3395559</a>	Wire
43	<a href="#">3179795</a>		Screw, Ground
44	<a href="#">3957824</a>		Knob, Timer
"	<a href="#">3957822</a>		Knob, Timer
45	<a href="#">3957849</a>		Dial, Timer
"	<a href="#">3957850</a>		Dial, Timer
46	<a href="#">8536939</a>		Clip, Knob
47	<a href="#">3957799</a>		Knob, Control
"	<a href="#">3957797</a>		Knob, Push-To-Start
49	<a href="#">388326</a>		Screw, 8-18 X 1.25
50	62863	<a href="#">3390631</a>	Screw, 10-16 X 3/8
51	8271359	<a href="#">279962</a>	Endcap
"	8271362	<a href="#">279965</a>	Endcap
52	<a href="#">8559320</a>		Restraint, Hose
53	3366913	<a href="#">3357331</a>	Clamp, Drain
54	<a href="#">3954795</a>		Harness, Wiring
55	<a href="#">3357027</a>		Nozzle, Hose Drain
56	8317940	<a href="#">W10358149</a>	Drain Hose Assembly
"	N/A	Not Available	FOLLOWING PARTS NOT ILLUSTRATED
"	3976253	<a href="#">285654</a>	Parts-Misc