


Whirlpool 4PLBR8543JQ3 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Models: 4PLBR8543JQ3, 4PLBR8543JT3
(Designer White) (Biscuit)

AUTOMATIC WASHER



3-06 Litho in U.S.A. (drd)

1

Part No. 8181170

Whirlpool [Residential Whirlpool 4PLBR8543JQ3 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8316568		Not Available	Installation Instructions Use & Care Guide
"	8315981		Not Available	English/Korean
"	3954823		Not Available	Arabic
"	3954743		Not Available	Wiring Diagram
2	8271408			Top
"	8271410			Top
4	357213			Nut, Push-In
5	63128			Cabinet
"	3954777			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3948451			Cabinet -Sound Damper
8	3356311			Screw And Washer, Lid Switch Shield
9	3357011	308685		Side Trim)
11	3949239	3949247		Switch-Lid

13	3351355	W10119828	Screw, Lid Hinge Mounting
15	54584		Hinge, Lid
16	91770		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8316048	3957510	Lid
"	8316055	3957511	Lid
20	358684		Strike, Lid Switch
21	9724509		Bumper, Lid
22	3390631		Screw, 10-16 X 3/8
23	90016		Clip, Pressure Switch Hose
24	3362952		Dispenser, Bleach

the laundry company[®]

the laundry company[®]

the laundry company[®]