


# Whirlpool 6ALBR6245MW0 03 - AGITATOR, BASKET AND TUB PARTS



Whirlpool Residential Whirlpool 6ALBR6245MW0 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">63580</a>			Dispenser, Fabric Softener
2	<a href="#">358237</a>			Screw And Washer
3	<a href="#">3354845</a>			Clip, Agitator
4	<a href="#">3350830</a>			Agitator
5	<a href="#">3950568</a>			Tub Ring And Gasket
6	<a href="#">3359586</a>			Gasket, Tub Ring
7	<a href="#">8519815</a>			Clip, Balance Ring
8	<a href="#">3956205</a>			Balance Ring
10	3355921	<a href="#">8543666</a>		Washer, Agitator
11	<a href="#">3363661</a>			Bearing, Driven Cam
12	<a href="#">21366</a>			Nut, Spanner
13	<a href="#">8312681</a>			Basket
14	<a href="#">63125</a>			Tub
15	<a href="#">389140</a>			Tub Block, Basket Drive
16	<a href="#">383727</a>			Gasket, Centerpod
17	3363657	<a href="#">353244</a>		Hose, Pressure Switch

19	3363663	<a href="#">285811</a>	Cam-Agitator
20	3366877	<a href="#">80040</a>	Dog-Agitator
22	3350389	<a href="#">285587</a>	Washer
23	3354733	<a href="#">W10074580</a>	Cap, Barrier
24	3348855	<a href="#">W10072840</a>	Fabric Softener
26	<a href="#">3949550</a>		Washer
27	3350829	<a href="#">285574</a>	Large Ring
28	<a href="#">3349019</a>		Auger, Agitator

