


Whirlpool 6ALSR7244MW3 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Model: 6ALSR7244MW3
(White/Grey)



8181058

5

Whirlpool [Residential Whirlpool 6ALSR7244MW3 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8533251			Dispenser, Fabric Softener
2	358237			Screw And Washer
3	3360824			Auger, Agitator
4	389386			Agitator
5	8528150	W10445870		Ring-Tub
6	3976308			Gasket, Tub Ring
7	3354845			Clip, Agitator
8	3363661			Bearing, Driven Cam
9	3363662	285748		Cam-Agitator
10	3366877	80040		Dog-Agitator
11	8519788	387240		Ring, Balance
12	21366			Nut, Spanner
13	8541746			Basket And Balance Ring
14	3949550			Washer
15	8543666			Washer, Agitator
16	63849			Strain Relief, Power Cord

17	389140		Tub Block, Basket Drive
18	383727		Gasket, Centerpodt
19	3347780	353244	Hose, Pressure Switch
20	3361598	285727	Agitator
21	3350389	285587	Washer
22	2219077		Clip, Pressure Switch Hose

