


Whirlpool 6AWTW5550XW0 02 - CONSOLE AND DISPENSER PARTS

CONSOLE AND DISPENSER PARTS

For Model: 6AWTW5550XW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10407658

3

Whirlpool [Residential Whirlpool 6AWTW5550XW0 Washer Parts](#) Parts Diagram 02 - CONSOLE AND DISPENSER PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10331123			Console
2	W10251392			Knob Assembly
3	W10362632			User Interface
4	W10219342			Screw, Baffle Mounting
5	8312709			Clip-Console
6	W10365813	W10445404		Control Unit Assembly, Machine And Motor
7	W10269597			Panel, Console Rear Cover
8	3390647	488729		Screw
9	1157158	489069		Xxscrew, 10-12 X 1/2
10	W10280079			Seal, Console
11	W10332929			Cord, Power
12	3400076			Screw, Bracket Mounting
13	W10287482			Housing Assembly - Dispenser
14	W10240976			Valve, Cold Water Inlet
15	W10240975			Valve, Hot Water Inlet

16	W10368547		Harness, Valve
17	3400061		Screw, Dispenser Housing Mounting
18	97787	W10109200	Screw, Baffle Mounting
19	W10240946		Bezel, Dispenser
20	W10240958		Drawer, Dispenser Assembly
21	359625	487240	Screw, For Mtg. Service Capacitor
22	9740848		Screw, Mixing Valve Mounting
23	W10325119		Spacer, Knob
24	8536939		Clip, Knob
25	W10274524		Tensioner, Facia
26	W10285493		Harness, User Interface
27	3949383		Hose, Water Inlet
"	3949382		Hose, Water Inlet
28	W10242307	16123	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
29	3357397		Adapter, Water Inlet Hose
30	3357450		Washer, Water Inlet Hose
31	W10386510		Washer, Inlet Hose Adapter

