


# Whirlpool 7EWTW1409YM0 02 - CONTROLS AND WATER INLET PARTS



Whirlpool [Residential Whirlpool 7EWTW1409YM0 Washer Parts](#) Parts Diagram 02 - CONTROLS AND WATER INLET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10410366</a>			Panel, Console
2	<a href="#">8536939</a>			Clip, Knob
3	8566035	<a href="#">8565957</a>		Cap, End
4	8566032	<a href="#">8565954</a>		Cap, End
5	<a href="#">8312709</a>			Clip-Console
6	<a href="#">W10445355</a>			Control Unit Assembly, Machine And Motor
7	W10251310	<a href="#">W10420985</a>		Panel, Console Rear Cover
8	1157158	<a href="#">489069</a>		Xxscrew, 10-12 X 1/2
9	<a href="#">W10268910</a>			Switch, Water Level
10	<a href="#">90767</a>			Screw, 8A X 3/8 HeX Washer Head Tapping
11	<a href="#">W10276649</a>			Cord, Power
12	<a href="#">3400076</a>			Screw, Bracket Mounting
13	<a href="#">W10034750</a>			Timer Knob Assembly
14	<a href="#">W10034380</a>			Knob, Control

15	<a href="#">W10285511</a>		Switch, Rotary Encoder
16	<a href="#">W10291174</a>		Harness, Upper
17	<a href="#">W10357189</a>		Inlet Assembly, Water
18	<a href="#">W10352256</a>		Valve, Water Mixing
19	W10334611	<a href="#">W10441423</a>	Vacuum Break
20	<a href="#">W10238347</a>		Hose, Vacuum Break
21	W10117298	<a href="#">596669</a>	Clamp, Manifold
22	<a href="#">W10344775</a>		Harness, Valve
23	<a href="#">8281163</a>		Screw, Dispenser Housing Mounting
24	<a href="#">3400818</a>		Screw, Timer Mounting
25	<a href="#">W10348582</a>		Cable Tie
26	<a href="#">W10285512</a>		Switch, Rotary Encoder
27	<a href="#">W10251309</a>		Pushbutton, Start
28	W10242307	<a href="#">16123</a>	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
29	W10194210	<a href="#">89503</a>	Hose-Inlet
"	W10196191	<a href="#">89503</a>	Hose-Inlet
30	353362	<a href="#">285452</a>	Hose Screen
31	<a href="#">W10269488</a>		Connector- Hose, Y
32	<a href="#">3357450</a>		Washer, Water Inlet Hose

