


Whirlpool 7MBP11973MQ1 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

FOR MODEL: 7MBP11973MQ1
(Designer White)



8180148

5

Whirlpool Residential Whirlpool 7MBP11973MQ1 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	63580			Dispenser, Fabric Softener
2	358237			Screw And Washer
3	64210			Extension, Agitator
4	64214			Agitator
5	8528150	W10445870		Ring-Tub
6	3976308			Gasket, Tub Ring
11	63027	W10109200		Screw, Baffle Mounting
12	21366			Nut, Spanner
13	8526017	W10389329		Clothes Container, Assembly
14	8519788	387240		Ring, Balance
16	63849			Strain Relief, Power Cord
17	389140			Tub Block, Basket Drive
18	383727			Gasket, Centerpod
19	3347780	353244		Hose, Pressure Switch
22	3354845			Clip, Agitator
23	3355921	8543666		Washer, Agitator

