


Whirlpool 7MGHW9400PW1 03 - CONTROL PANEL PARTS



8181280

5

Whirlpool [Residential Whirlpool 7MGHW9400PW1 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8182784			Panel, Control
2	8182717			User Interface
3	8181860			Button, Power
4	8182188			Button, Start
5	8181863			Button Set, Soil Level
6	8182275			Button, Pause/Cancel
7	8181864			Button Set, Options
8	8181865			Button Set, Spin/Temperature
13	8182224		Not Available	Brace, Front Top
14	8182800			Channel, Water
15	8182788			Microcomputer, Machine Control
16	8181756	488729		Screw
17	8182212			Harness, Wiring
19	8181854			Handle, Drawer
20	8181855			Bezel, Knob
21	8181857			Overlay, Door

22	8181858	8303811	Badge, Assembly
23	8181859		Knob, Control
24	8181852		Endcap, Left
25	8181853		Endcap, Right

