


# Whirlpool 7MLBR8444PT1 03 - AGITATOR, BASKET AND TUB PARTS

## AGITATOR, BASKET AND TUB PARTS

For Models: 7MLBR8444PQ1, 7MLBR8444PT1  
(Designer White) (Biscuit)



8180770

5

Whirlpool [Residential Whirlpool 7MLBR8444PT1 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">63580</a>			Dispenser, Fabric Softener
2	<a href="#">358237</a>			Screw And Washer
4	<a href="#">64214</a>			Agitator
5	<a href="#">3360611</a>			Tub Ring And Gasket Assembly
6	<a href="#">3359586</a>			Gasket, Tub Ring
7	<a href="#">8519815</a>			Clip, Balance Ring
8	<a href="#">3956205</a>			Balance Ring
11	63027	<a href="#">W10109200</a>		Screw, Baffle Mounting
12	<a href="#">21366</a>			Nut, Spanner
13	3956206	<a href="#">3956207</a>		Basket And Balance Ring
14	<a href="#">63125</a>			Tub
15	<a href="#">389140</a>			Tub Block, Basket Drive
16	<a href="#">383727</a>			Gasket, Centerpod
17	3363657	<a href="#">353244</a>		Hose, Pressure Switch
18	<a href="#">2219077</a>			Clip, Pressure Switch Hose

20

[64210](#)

Extension, Agitator

22

[3354845](#)

Clip, Agitator

23

[8543666](#)

Washer, Agitator

26

[3949550](#)

Washer

