Whirlpool 7MLSR5132JQ4 08 - GEARCASE PARTS



Whirlpool Residential Whirlpool 7MLSR5132JQ4 Washer Parts Parts Diagram 08 - GEARCASE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8532118	3360629		Gearcase
2	285202			Cover, Gearcase
3	3349985			Seal, Gearcase Cover
4	285195			Sealer Sealer, Gasket
5	63320	285362		Gear and Pinon
6	356427			Seal, Spin Pinion
7	389387			Shaft, Agitator
8	90369		Not Available	Ring, Retaining (2)
9	62677			Retainer, Spring
10	62676			Spring, Agitator
11	63273	285509		Shaft, Agitator
12	62619			Washer, Agitator Gear
13	62580	285206		Cam-Agitator
14	62581	285206		Cam-Agitator
15	285509			Shaft, Agitator
16	62618			Washer, Cam Thrust

17	16018	285205		Bearing
18	85529	285205		Bearing
19	389230	285515		Gearcase
20	3949116		Not Available	BLOCK TAB, TERMINAL
21	285352			Seal Kit, Thrust Plug
22	3351614			Screw, Gearcase Cover Mounting
23	3362552	285765		Ring-Retnr
24	285735	285766		Washer Kit, Thrust
25	62570	285362		Gear and Pinon
26	388253	999516		Shelf-Glas
27	3349296	8546456		Rack, Connecting
28	62621			Actuator, Shift
29	388815			Washer, Intermediate 1 3976263 Miscellaneous Parts Bag 2 3976300 Washer, Inlet Hose 3 3366913 Clamp, Hose

the laundry company®
the laundry company®
the laundry company®