


Whirlpool 7MLSR6232JT3 01 - TOP AND CABINET PARTS



Whirlpool Residential Whirlpool 7MLSR6232JT3 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3954763		Not Available	Literature Parts (Installation Instructions)
"	LIT8532147		Not Available	Literature Parts (Use & Care Guide)
"	LIT8532072		Not Available	Literature Parts (Energy Guide (Mexico))
"	LIT3954905		Not Available	Literature Parts (Wiring Diagram)
2	8274317			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	3954357			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3357011	308685		Side Trim)
8	3356311			Screw And Washer, Lid Switch Shield
10	3950994			Shield, Lid Switch
11	3950298			Switch, Lid

12	3400901	680762	Nut
13	3351355	W10119828	Screw, Lid Hinge Mounting
14	3351614		Screw, Gearcase Cover Mounting
15	54584		Hinge, Lid
16	91770		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	3954599	W10193875	Lid
20	357913	358684	Strike, Lid Switch
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8
31	90016		Clip, Pressure Switch Hose

the laundry company[®]

the laundry company[®]

the laundry company[®]