


# Whirlpool 7MLSR6332KQ2 03 - AGITATOR, BASKET AND TUB PARTS



8179994

5

Whirlpool [Residential Whirlpool 7MLSR6332KQ2 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3355758</a>			Cap, Agitator
2	<a href="#">358237</a>			Screw And Washer
3	<a href="#">3348752</a>			Mover, Clothes
4	<a href="#">3347288</a>			Agitator
5	8528150	<a href="#">W10445870</a>		Ring-Tub
6	3359585	<a href="#">3976308</a>		Gasket, Tub Ring
9	3363663	<a href="#">285811</a>		Cam-Agitator
10	3366877	<a href="#">80040</a>		Dog-Agitator
11	<a href="#">3363661</a>			Bearing, Driven Cam
12	<a href="#">21366</a>			Nut, Spanner
13	3951989	<a href="#">W10389329</a>		Clothes Container, Assembly
16	<a href="#">63849</a>			Strain Relief, Power Cord
17	<a href="#">389140</a>			Tub Block, Basket Drive
18	<a href="#">383727</a>			Gasket, Centerpodt
19	3347780	<a href="#">353244</a>		Hose, Pressure Switch
20	3348117	<a href="#">285565</a>		Agitator

22	3350389	<a href="#">285587</a>	Washer
23	3354733	<a href="#">W10074580</a>	Cap, Barrier
24	3348855	<a href="#">W10072840</a>	Fabric Softener
26	8544817	<a href="#">3949550</a>	Washer

