


# Whirlpool 7MLSR8534PG1 01 - TOP AND CABINET PARTS



Whirlpool [Residential Whirlpool 7MLSR8534PG1 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS  
Click on the part number to view part

| Item | Original Part Number    | Replaced By            | Status        | Part Description                     |
|------|-------------------------|------------------------|---------------|--------------------------------------|
| 1    | 8316475                 |                        | Not Available | Installation Instructions            |
| "    | 8558603                 |                        | Not Available | Feature Sheet                        |
| "    | 8558605                 |                        | Not Available | Energy Guide (Mexico)                |
| "    | 8539806                 |                        | Not Available | Use & Care Guide                     |
| "    | 8543288                 |                        | Not Available | Wiring Diagram                       |
| 2    | <a href="#">8318064</a> |                        |               | Top                                  |
| "    | <a href="#">8318066</a> |                        |               | Top                                  |
| 3    | 62750                   |                        |               | Spacer, Cabinet To Top (4)           |
| 4    | 3357011                 | <a href="#">308685</a> |               | Side Trim )                          |
| 5    | <a href="#">63424</a>   |                        |               | Cabinet                              |
| "    | <a href="#">3954357</a> |                        |               | Cabinet                              |
| 6    | <a href="#">62780</a>   |                        |               | Clip, Top And Cabinet And Rear Panel |
| 7    | <a href="#">3362952</a> |                        |               | Dispenser, Bleach                    |
| 8    | <a href="#">3351614</a> |                        |               | Screw, Gearcase Cover Mounting       |
| 9    | <a href="#">357213</a>  |                        |               | Nut, Push-In                         |

|    |                         |                           |                           |
|----|-------------------------|---------------------------|---------------------------|
| 11 | <a href="#">8318084</a> |                           | Switch, Lid               |
| 12 | 8533959                 | <a href="#">680762</a>    | Nut                       |
| 13 | 3351355                 | <a href="#">W10119828</a> | Screw, Lid Hinge Mounting |
| 15 | <a href="#">8318088</a> |                           | Hinge, Lid                |
| 16 | <a href="#">54583</a>   |                           | Hinge, Lid                |
| 17 | <a href="#">19119</a>   |                           | Bumper, Lid Hinge         |
| 18 | <a href="#">21258</a>   |                           | Bearing, Lid Hinge        |
| 19 | 8557513                 | <a href="#">3957617</a>   | Lid                       |
| "  | 8557514                 | <a href="#">3957618</a>   | Lid                       |
| 22 | <a href="#">9724509</a> |                           | Bumper, Lid               |
| 28 | <a href="#">3390631</a> |                           | Screw, 10-16 X 3/8        |

