


Whirlpool 7MLSR8534PG1 02 - CONTROLS AND REAR PANEL PARTS



8180767

3

Whirlpool [Residential Whirlpool 7MLSR8534PG1 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	3351614			Screw, Gearcase Cover Mounting
3	8571377	89503		Hose-Inlet
"	8571378	89503		Hose-Inlet
4	9740848			Screw, Mixing Valve Mounting
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	8559373	W10096921		Drain Hose Assembly
9	3949208			Timer, Control
10	8055003			Clip, Harness And Pressure Switch
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	3366847	W10337780		Switch-WL

13	8544893		Bracket, Control
14	8559419		Cord, Power
15	8559337	285777	Relief-Str
16	8271369	279962	Endcap
"	8314852		Cap, End
17	8318046		Clip, Capacitor
18	3952164	285805	Valve-Inlet
19	8541668		Clamp, Hose
20	3179795		Screw, Ground
21	301958	596669	Clamp, Manifold
22	8541607	3357328	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	303294	3367669	Protector, Edge
26	8572717		Capacitor, Motor Start
27	8541667		Clamp, Hose
28	3400985		Medallion
29	8519200		Support, Rear Panel
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3347868	W10339879	Tie, Cable
34	8317975		Restraint, Harness
35	661612	W10168256	Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	3949187	W10168262	Switch, Rotary
38	8541672	8577378	U-Bend, Drain Hose
39	8539642		Panel, Console
"	8539644		Panel, Console
"	8539643		Panel, Console
"	8546305		Panel, Console
40	8541669		Bucket, Drain Hose
"	BLANK	Not Available	(Left Half)
41	357572	W10113937	Clip, Grounding
42	3398893	3395559	Wire
43	8541658		Bucket, Drain Hose
"	BLANK	Not Available	(Right Half)
44	8544943		Knob, Timer
"	8544944		Knob, Timer
"	8544945		Knob, Timer
"	8544946		Knob, Timer
45	8544947		Dial, Timer
"	8544948		Dial, Timer
46	8536939		Clip, Knob
47	8544935		Knob, Control
"	8544936		Knob, Control
"	8544937		Knob, Control
"	8544938		Knob, Control
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8271363	279962	Endcap
"	8314851		Cap, End

