


Whirlpool 7MSAWS800LQ1 01 - TOP AND CABINET PARTS



5-03 Litho in U.S.A. (drd)

1

Part No. 8180000

Whirlpool Residential Whirlpool 7MSAWS800LQ1 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3954763		Not Available	Literature Parts (Installation Instructions)
"	LIT8539754		Not Available	Literature Parts (Use & Care Guide)
"	LIT8539722		Not Available	Literature Parts (Energy Guide)
"	LIT3955653		Not Available	Literature Parts (Wiring Diagram)
2	8271378			Top
3	62750			Spacer, Cabinet To Top (4
4	3357011	308685		Side Trim)
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	357213			Nut, Push-In
8	3356311			Screw And Washer, Lid Switch Shield
9	3351614			Screw, Gearcase Cover Mounting
10	3950994			Shield, Lid Switch

11	3950298		Switch, Lid
12	3400901	680762	Nut
13	3351355	W10119828	Screw, Lid Hinge Mounting
15	54584		Hinge, Lid
16	91770		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8532145	285922	Lid
20	357913	358684	Strike, Lid Switch
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8
31	90016		Clip, Pressure Switch Hose
32	3362952		Dispenser, Bleach

the laundry company[®]

Howes
the laundry company[®]

Howes
the laundry company[®]