


Whirlpool 7MTAWS800JQ4 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 7MTAWS800JQ4 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	9740848			Screw, Mixing Valve Mounting
3	3949374	89503		Hose-Inlet
"	3949375	89503		Hose-Inlet
4	3357027			Nozzle, Hose Drain
5	8318255	8568314		Strap, Console
6	8318405			Panel, Rear
7	62747			Pad, Rear Panel
8	3951609	285664		Hose
"	661577	285666		Hose
"	3357090	285702		Hose
9	3948852			Timer, Control
10	8055003			Clip, Harness And Pressure Switch
11	3351614			Screw, Gearcase Cover

11	3531014		Mounting
12	3366846	W10335056	Switch-WL
13	3948608		Bracket, Control
14	8532158	W10130795	Cord-Power
15	3949468	285777	Relief-Str
16	8532108		Cap, End
17	3179795		Screw, Ground
18	3952164	285805	Valve-Inlet
19	3976395		Restraint, Hose
20	8318201	8318046	Clip, Capacitor
21	370451	596669	Clamp, Manifold
22	3357328		Hose, Vacuum Break
23	371503	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	303294	3367669	Protector, Edge
26	8317940	W10358149	Drain Hose Assembly
27	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
28	3366912	356138	Clamp, Hose
29	661606	8572717	Capacitor, Motor Start
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3976286		Shield, Capacitor
35	661614		Switch, Water Temperature
36	3400818		Screw, Timer Mounting
39	8531979		Panel, Console
41	357572	W10113937	Clip, Grounding
42	3398893	3395559	Wire
44	3951026	3957821	Knob, Timer
45	3950762	3957841	Dial, Timer
47	3950759	3957796	Knob, Control
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8532107		Cap, End
56	3366913	3357331	Clamp, Drain
59	8314879		Shield, Inlet Valve
60	3956136		Harness, Wiring

the laundry company[®]