


Whirlpool 7MTAWS800JQ4 03 - AGITATOR, BASKET AND TUB PARTS



8179990

5

Whirlpool [Residential Whirlpool 7MTAWS800JQ4 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	63580			Dispenser, Fabric Softener
2	358237			Screw And Washer
3	3348752			Mover, Clothes
5	3347288			Agitator
6	8528150	W10445870		Ring-Tub
7	3359585	3976308		Gasket, Tub Ring
8	21366			Nut, Spanner
9	3951989	W10389329		Clothes Container, Assembly
11	63849			Strain Relief, Power Cord
12	3363661			Bearing, Driven Cam
13	389140			Tub Block, Basket Drive
14	383727			Gasket, Centerpod
15	3347780	353244		Hose, Pressure Switch
16	3348117	285565		Agitator
17	8544817	3949550		Washer
18	3366877	80040		Dog-Agitator

20	3354733	W10074580	Cap, Barrier
21	3348855	W10072840	Fabric Softener
22	3363663	285811	Cam-Agitator
23	3350389	285587	Washer
24	3354845		Clip, Agitator
25	3355921	8543666	Washer, Agitator

