


Whirlpool 7MWG87660SM0 01 - TOP AND CONSOLE PARTS



2-07 Litho in U.S.A. (LT)

1

Part No. W10130484 Rev.A.

Whirlpool [Residential Whirlpool 7MWG87660SM0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8564241		Not Available	Instructions, Installation
"	8579961		Not Available	Sheet, Cycle Feature
"	8565897		Not Available	Use And Care Guide
"	8576811		Not Available	Wiring Diagram
"	BLANK		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	677818		Not Available	Manual, Do-It- Yourself Repair (Dryer)
2	8533951	3400859		Screw, Grounding
3	3394427			Clip-Harness
4	8565957			Cap, End
5	3397269			Connector, Timer
6	8274261			Do-It-Yourself Repair Manuals
7	3395683			Receptacle, Multi-Terminal
8	8565954			Cap, End
9	694419			Mini-Buzzer

10	8557857		Screen, Lint
11	8536939		Clip, Knob
12	8312709		Clip-Console
13	688983	487240	Screw, For Mtg. Service Capacitor
14	3401684		Jumper, Wire
15	693995		Screw, Hex Head
16	8559800	8563663	Top
17	3396029	8539893	Wire, Jumper
18	3405156		Switch, Rotary
19	8565944		Knob, Control
20	3397695		Wire, Jumper
21	8299766		Timer Assembly
22	3403499		Connector, 2-Postion
23	3403498		Connector, 3-Position
24	3347243		Block, Disconnect
25	3399639		Switch, Rotary Temperature
29	8533971	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
31	8299879		Harness, Wiring
32	3398095		Switch, Push-To-Start
33	8566061		Timer Knob Assembly
34	8566073		Knob, Push-To-Start
35	717252		Receptacle, Terminal
36	94614		Terminal
37	8566052		Bracket, Console
38	W10112103		Panel, Control
39	3936144		Do-It-Yourself Repair Manuals

the laundry company[®]

the laundry company[®]