


Whirlpool 7MWGD9015YW1 02 - CABINET PARTS



Whirlpool Residential Whirlpool 7MWGD9015YW1 Dryer Parts Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3390631			Screw, 10-16 X 3/8
2	343641	681414		Screw, 10AB X 1/2
3	3404162			Clamp, Motor
4	W10236073			Bracket, Cabinet
5	3396795			Cover, Terminal Block
6	693995			Screw, Hex Head
7	3396805	280043		Panel-Rear
8	341029			Clamp, Pipe Door Spring
9	W10121316			Plug, Multivent
10	3406107			Door Switch Assembly
11	697773	3395530		Screw
12	3980175			Clamp, Elbow
13	342055	488627		Screw
14	W10041960			Spring, Door
15	3357011	308685		Side Trim)
16	3392100	49621		Feet-Leveling

NI	279810		Foot-Optional
17	8066206	279827	Motor-Drive
18	8530603	8533643	Cabinet
19	98234		Clip, U-Bend
20	690363	18776	Lock, Front Top
21	3395197	279740	Panel
22	8066184		Pulley, Motor
23	685203	279220	Clip
24	3389441		Door Catch Assembly
25	3390731		Seal, Door
26	337189		Clip, Hinge
27	3390647	488729	Screw
28	8066056		Hinge, Door
"	8066057		Hinge, Door
29	3394083		Clip, Front Panel
30	3400500		Bolt, 3405245 5/16-18 X 3/4
31	348780		Base, Motor
32	W10131364	341241	Belt
33	696144	279570	Latch
34	691366		Idler And Pulley Assembly
35	695737		Door, Rear
36	3393549		Door, Front
37	W10095180		Handle, Door
38	3406129		Seal And Bearing Assembly
39	W10440460		Cord, Power
40	8564457		Plug, Front Panel
41	8066217		Hinge, Top
42	W10336852	W10465748	Burner-Gas

the laundry company[®]

the laundry company[®]