


Whirlpool 7MWGD9150XW1 05 - DOOR PARTS

DOOR PARTS

For Model: 7MWGD9150XW1
(White)



W10364747

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

9

Whirlpool [Residential Whirlpool 7MWGD9150XW1 Dryer Parts](#) Parts Diagram 05 - DOOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10256915			Label, Hinge Hole Cover
2	W10304672	8578887		Door Hinge Assembly
3	3393258	3373329D		Screw
4	8534044			Screw, 8-18 X 1/2
5	W10215766			Door Trim, Hinge Cover
6	8579663			Seal, Window
7	8534022			Screw, 8-18 X 1/16
8	W10159996			Screw, 10-24 X 25/64
9	W10215761			Screen, Door
10	W10198441	W10363674		Door Assembly
11	355515			Screw, 8-18 X 11/16
12	W10215757			Trim, Door Ring Outer
13	W10286878			Window
14	690081	279570		Latch
15	8519354			Retainer-Window
16	W10215762	W10431338		Door

17	8519356		Retainer-Window
18	9742177		Screw, 8-18 X .625
19	W10163915		Door Seal
20	W10215759	W10215755	Door Assembly Outer
21	W10215764		Door, Intermediate Stationary
22	W10215755		Door Assembly Outer

