


# Whirlpool 7MWGD9200TQ0 01 - TOP AND CONSOLE PARTS



## TOP AND CONSOLE PARTS

For Models: 7MWGD9200TQ0  
(Designer White)

27" GAS DRYER



9-07 LITHO IN U.S.A. (LT)

1

Part No. W10163482 Rev. A

Whirlpool [Residential Whirlpool 7MWGD9200TQ0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10140906		Not Available	Use & Care Guide
"	W10140907		Not Available	Tech Sheet
"	W10140905		Not Available	Guide, Quick Start
2	3980634	<a href="#">W10117263</a>		Top
3	<a href="#">8579737</a>			Harness, Main
4	<a href="#">W10116694</a>			Panel, Console
5	<a href="#">3394427</a>			Clip-Harness
6	W10006840	<a href="#">W10215656</a>		Bracket, Console
7	<a href="#">353424</a>			Plug, Terminal
8	<a href="#">94614</a>			Terminal
9	<a href="#">3936144</a>			Do-It-Yourself Repair Manuals
10	94613	<a href="#">596797</a>		Terminal
11	3390647	<a href="#">488729</a>		Screw
12	<a href="#">W10112267</a>			Foam-Seal Control Bracket
13	W10030070	<a href="#">W10012480</a>		Kit
14	<a href="#">3936150</a>			Connector, 7-Circuit

15	<a href="#">3395683</a>		Receptacle, Multi-Terminal
16	3390647	<a href="#">488729</a>	Screw
17	<a href="#">2203186</a>		Connector, 5-Circuit
18	W10031420	<a href="#">W10294578</a>	Kit
19	<a href="#">W10031410</a>		User Interface
20	<a href="#">W10012430</a>		Encoder, Wheel Kit.
21	<a href="#">W10012440</a>		Retainer-Snap
22	<a href="#">W10012410</a>		Knob, Light Ring
23	W10012810	<a href="#">280230</a>	Encoder, Wheel Kit.
24	W10012450	<a href="#">280230</a>	Encoder, Wheel Kit.
25	<a href="#">W10112268</a>		Clip-Harness
26	W10012820	<a href="#">280230</a>	Encoder, Wheel Kit.
27	<a href="#">W10116701</a>		Knob, Control
28	<a href="#">280230</a>		Encoder, Wheel Kit.
29	<a href="#">W10095960</a>		Harness, Communication
30	<a href="#">3391018</a>		Tie Cable
31	<a href="#">W10110976</a>		Cube, Cable
32	W10117943	<a href="#">8303811</a>	Badge, Assembly

