


Whirlpool 7MWS89700SM0 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 7MWS89700SM0 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	694419			Mini-Buzzer
3	8571377	89503		Hose-Inlet
"	8571378	89503		Hose-Inlet
4	3400073			Screw, Ground
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	8559373	W10096921		Drain Hose Assembly
9	3955765			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	3366845	W10339326		Switch-WL

13	8566003		Bracket, Control
14	W10115689		Cord, Power
15	3952821	285777	Relief-Str
16	8565957		Cap, End
17	8317975		Restraint, Harness
18	3979347	3979346	Valve, Water Inlet And Thermistor Assembly
19	8565954		Cap, End
20	8318046		Clip, Capacitor
21	301958	596669	Clamp, Manifold
22	8055003		Clip, Harness And Pressure Switch
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	3347868	W10339879	Tie, Cable
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	8572720		Capacitor, Motor Start
29	3407173		Control, Atc
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	8541668		Clamp, Hose
34	3950356		Switch, Rotary
35	62863	3390631	Screw, 10-16 X 3/8
36	3400818		Screw, Timer Mounting
37	3407174		Transformer
38	3955774	W10168360	Switch, Water Temperature
39	W10096796		Panel, Console
40	8312709		Clip-Console
41	8316039		Shield, Atc
42	3956080		Switch, Rotary
43	8317974	8317926	Hose, Vacuum Break
44	8566022		Knob, Timer
45	8566018		Dial,
46	8565944		Knob, Control
47	8536939		Clip, Knob
48	8577378		U-Bend, Drain Hose
49	9740848		Screw, Mixing Valve Mounting
50	8314879		Shield, Inlet Valve
51	W10066870		Harness, Wiring
52	8541669		Bucket, Drain Hose
53	8541658		Bucket, Drain Hose