


Whirlpool 7MWT74500SQ0 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Model: 7MWT74500SQ0
(Designer White)



8181318

5

Whirlpool [Residential Whirlpool 7MWT74500SQ0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3355758			Cap, Agitator
2	358237			Screw And Washer
4	63235			Agitator Assembly
5	3360611			Tub Ring And Gasket Assembly
6	3359586			Gasket, Tub Ring
7	8519815			Clip, Balance Ring
8	3956205			Balance Ring
10	2219077			Clip, Pressure Switch Hose
12	21366			Nut, Spanner
13	3956206	3956207		Basket And Balance Ring
14	63125			Tub
15	389140			Tub Block, Basket Drive
16	383727			Gasket, Centerpod
17	3363657	353244		Hose, Pressure Switch
26	3949550			Washer