


Whirlpool 7MWT74500SQ2 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 7MWT74500SQ2 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10242307	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	W10194210	89503		Hose-Inlet
"	W10196191	89503		Hose-Inlet
3	3347868	W10339879		Tie, Cable
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	W10153017			Panel, Rear
7	62747			Pad, Rear Panel
8	W10189267			Drain Hose Assembly
9	W10199989			Timer, Control
10	9740848			Screw, Mixing Valve Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577845	W10339334		Switch-WL
13	3948814			Bracket, Control

14	W10115689		Cord, Power
15	3952821	285777	Relief-Str
16	8271365	279962	Endcap
17	8271359	279962	Endcap
18	W10140918		Valve, Water Inlet W/Vacuum Break
19	3400985		Medallion
20	8572717		Capacitor, Motor Start
21	8566022		Knob, Timer
22	8566018		Dial,
23	8565944		Knob, Control
24	8536939		Clip, Knob
25	303294	3367669	Protector, Edge
26	8541668		Clamp, Hose
27	W10000080	8282566	Clip, Pine Tree
28	62863	3390631	Screw, 10-16 X 3/8
29	8519200		Support, Rear Panel
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3349557		Retainer, Harness
34	388326		Screw, 8-18 X 1.25
35	661612	W10168256	Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	3400073		Screw, Ground
38	8318046		Clip, Capacitor
39	W10222533		Panel, Console
40	3351614		Screw, Gearcase Cover Mounting
41	W10235787		Harness, Wiring

