


Whirlpool 7MWT74500SQ2 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Model: 7MWT74500SQ2
(White)



W10247214

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

5

Whirlpool [Residential Whirlpool 7MWT74500SQ2 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3355758			Cap, Agitator
2	358237			Screw And Washer
3	3949550			Washer
4	63235			Agitator Assembly
5	3360611			Tub Ring And Gasket Assembly
6	3359586			Gasket, Tub Ring
7	8519815			Clip, Balance Ring
8	3956205			Balance Ring
9	21366			Nut, Spanner
10	3956206	3956207		Basket And Balance Ring
11	63125			Tub
12	389140			Tub Block, Basket Drive
13	383727			Gasket, Centerpodt
14	2219077			Clip, Pressure Switch Hose
15	3363657	353244		Hose, Pressure Switch