


Whirlpool 7MWT74710SM0 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Model: 7MWT74710SM0
(White/Metallic)



8181300

5

Whirlpool [Residential Whirlpool 7MWT74710SM0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	63580			Dispenser, Fabric Softener
2	358237			Screw And Washer
3	3949550			Washer
4	64214			Agitator
5	3360611			Tub Ring And Gasket Assembly
6	3359586			Gasket, Tub Ring
7	8519815			Clip, Balance Ring
8	3956205			Balance Ring
9	3354845			Clip, Agitator
10	8543666			Washer, Agitator
11	63027	W10109200		Screw, Baffle Mounting
12	21366			Nut, Spanner
13	3956206	3956207		Basket And Balance Ring
14	63125			Tub
15	389140			Tub Block, Basket Drive

16	383727	Gasket, Centerpodt	
17	3363657	353244	Hose, Pressure Switch
18	2219077	Clip, Pressure Switch Hose	
19	64210	Extension, Agitator	

