


Whirlpool 7MWT96007XQ0 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 7MWT96007XQ0 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10242307	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	353362	285452		Hose Screen
3	W10194210	89503		Hose-Inlet
"	W10196191	89503		Hose-Inlet
4	9740848			Screw, Mixing Valve Mounting
5	8568314			Strap, Console
6	W10194450			Panel, Rear
7	62747			Pad, Rear Panel
8	W10189267			Drain Hose Assembly
9	W10185786			Timer, Control
10	8055003			Clip, Harness And Pressure Switch
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	W10231403			Switch, Water Level

13	8566003		Bracket, Control
14	W10115689		Cord, Power
15	3952821	285777	Relief-Str
16	8566035	8565957	Cap, End
17	8566032	8565954	Cap, End
18	W10278652		Valve, Water Inlet W/Vacuum Break
19	8541668		Clamp, Hose
20	3400073		Screw, Ground
21	8566022		Knob, Timer
22	8566018		Dial,
23	8565944		Knob, Control
24	8536939		Clip, Knob
25	8318046		Clip, Capacitor
26	8572717		Capacitor, Motor Start
27	W10000080	8282566	Clip, Pine Tree
28	8312709		Clip-Console
29	3351614		Screw, Gearcase Cover Mounting
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	661612	W10168256	Switch, Water Temperature
34	3949180	W10168257	Switch, Rotary
35	W10301508		Panel, Console
36	3400818		Screw, Timer Mounting
37	8519200		Support, Rear Panel
38	3347868	W10339879	Tie, Cable
39	8577378		U-Bend, Drain Hose
40	W10231379	W10251893	Clamp-Hose
41	62863	3390631	Screw, 10-16 X 3/8
42	W10235743		Harness, Wiring

