


Whirlpool 7MWT96500SQ2 02 - CONTROLS AND REAR PANEL PARTS

CONTROLS AND REAR PANEL PARTS

For Models: 7MWT96500SQ2, 7MWT96500ST2
(White) (Biscuit)



W10254675

3

Whirlpool Residential Whirlpool 7MWT96500SQ2 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10242307	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	9740848			Screw, Mixing Valve Mounting
3	W10194208	89503		Hose-Inlet
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	W10194450			Panel, Rear
7	62747			Pad, Rear Panel
8	W10189267			Drain Hose Assembly
9	W10185789			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577845	W10339334		Switch-WL
13	8544893			Bracket, Control

14	W10115689		Cord, Power
15	3952821	285777	Relief-Str
16	8271365	279962	Endcap
"	8271368	279965	Endcap
17	8271359	279962	Endcap
"	8271362	279965	Endcap
18	W10279103	Not Available	VALVE, WATER INLET W/VACUUM BREAK (SNGL PORT)
19	8541668		Clamp, Hose
20	62863	3390631	Screw, 10-16 X 3/8
21	8566022		Knob, Timer
"	8566025		Knob, Timer
22	8566018		Dial,
23	8565944		Knob, Control
"	8565947		Knob, Control
24	8536939		Clip, Knob
25	8318046		Clip, Capacitor
26	8519200		Support, Rear Panel
27	W10000080	8282566	Clip, Pine Tree
28	8055003		Clip, Harness And Pressure Switch
29	8572717		Capacitor, Motor Start
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3400073		Screw, Ground
34	3400985		Medallion
35	388326		Screw, 8-18 X 1.25
36	3400818		Screw, Timer Mounting
37	3347868	W10339879	Tie, Cable
38	W10222540		Panel, Console
"	W10222541		Panel, Console
39	W10243990		Harness, Wiring

