


Whirlpool 7MWT96540SQ2 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 7MWT96540SQ2 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10242307	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	9740848			Screw, Mixing Valve Mounting
3	W10194210	89503		Hose-Inlet
"	W10196191	89503		Hose-Inlet
4	3400073			Screw, Ground
5	8568314			Strap, Console
6	W10194450			Panel, Rear
7	62747			Pad, Rear Panel
8	W10189267			Drain Hose Assembly
9	W10199989			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577844	W10339251		Switch-WL

13	8544893		Bracket, Control
14	W10115689		Cord, Power
15	3952821	285777	Relief-Str
16	8271365	279962	Endcap
"	8271359	279962	Endcap
17	8271368	279965	Endcap
"	8271362	279965	Endcap
18	W10278652		Valve, Water Inlet W/Vacuum Break
19	8541668		Clamp, Hose
20	8318046		Clip, Capacitor
21	8566022		Knob, Timer
"	8566025		Knob, Timer
22	8566018		Dial,
23	8565944		Knob, Control
"	8565947		Knob, Control
24	8536939		Clip, Knob
25	W10000080	8282566	Clip, Pine Tree
26	661612	W10168256	Switch, Water Temperature
27	3400818		Screw, Timer Mounting
28	8572717		Capacitor, Motor Start
29	8519200		Support, Rear Panel
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	8055003		Clip, Harness And Pressure Switch
34	62863	3390631	Screw, 10-16 X 3/8
35	388326		Screw, 8-18 X 1.25
36	W10235788		Wiring Harness
37	8577378		U-Bend, Drain Hose
38	3347868	W10339879	Tie, Cable
39	W10222535		Panel, Console
"	W10222536		Panel, Console
40	3400985		Medallion

