


Whirlpool 7MWT98820WM0 03 - AGITATOR, BASKET AND TUB PARTS



Whirlpool Residential Whirlpool 7MWT98820WM0 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8528278			Dispenser, Fabric Softener
2	358237			Screw And Washer
3	3946996			Auger, Agitator
4	3947517			Agitator
5	8528150	W10445870		Ring-Tub
6	3976308			Gasket, Tub Ring
7	3354845			Clip, Agitator
8	8543666			Washer, Agitator
9	8537433			Cam, Driven
10	3366877	80040		Dog-Agitator
11	8055141			Bearing-Driven Cam
12	21366			Nut, Spanner
13	8526016	W10389328		Clothes Container, Assembly
14	387240			Ring, Balance
15	2219077			Clip, Pressure Switch Hose
16	63849			Strain Relief, Power Cord

17	389140		Tub Block, Basket Drive
18	383727		Gasket, Centerpodt
19	3347780	353244	Hose, Pressure Switch
20	8538246		Agitator
21	3949550		Washer
22	3946997		Spring, Compression
23	8533540		Retainer, Spring
24	8577198		Filter, Lint

