


# Whirlpool 7MWT98950TW0 03 - AGITATOR, BASKET AND TUB PARTS



Whirlpool Residential Whirlpool 7MWT98950TW0 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8580006</a>			Dispenser, Fabric Softener
2	<a href="#">358237</a>			Screw And Washer
3	<a href="#">3949550</a>			Washer
4	<a href="#">8578209</a>			Agitator, Complete Assembly
5	3954507	<a href="#">W10213410</a>		Ring-Tub
6	3359585	<a href="#">3976308</a>		Gasket, Tub Ring
7	<a href="#">3354845</a>			Clip, Agitator
8	<a href="#">8543666</a>			Washer, Agitator
9	<a href="#">8537434</a>			Cam, Driven
10	3366877	<a href="#">80040</a>		Dog-Agitator
11	<a href="#">8055141</a>			Bearing-Driven Cam
12	W10116603	<a href="#">W10116602</a>		Nut, Spanner
13	<a href="#">8579546</a>			Basket And Balance Ring
14	<a href="#">2219077</a>			Clip, Pressure Switch Hose
15	W10118233	<a href="#">W10006326</a>		Balance Ring
16	<a href="#">8283125</a>			Tub

17	<a href="#">389140</a>		Tub Block, Basket Drive
18	<a href="#">383727</a>		Gasket, Centerpodt
19	3347780	<a href="#">353244</a>	Hose, Pressure Switch
20	<a href="#">8578210</a>		Agitator, Complete Assembly
21	<a href="#">8054468</a>		Auger, Agitator
22	<a href="#">8055228</a>		Spacer, Thrust
23	3354733	<a href="#">W10074580</a>	Cap, Barrier
24	<a href="#">W10072840</a>		Fabric Softener
25	<a href="#">8533540</a>		Retainer, Spring
26	<a href="#">8055140</a>		Spring, Compression
27	<a href="#">8577198</a>		Filter, Lint
28	8318246	<a href="#">W10213410</a>	Ring-Tub
29	<a href="#">3948705</a>		Hose, Bleach

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>