


Whirlpool 7MWT98960WM1 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool Residential Whirlpool 7MWT98960WM1 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10242307	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	W10194210	89503		Hose-Inlet
"	W10196191	89503		Hose-Inlet
3	8055003			Clip, Harness And Pressure Switch
4	3400073			Screw, Ground
5	8568314			Strap, Console
6	W10194450			Panel, Rear
7	62747			Pad, Rear Panel
8	W10189267			Drain Hose Assembly
9	8577787			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577843	W10337781		Switch-WL

13	8566003		Bracket, Control
14	W10115689		Cord, Power
15	3952821	285777	Relief-Str
16	8566035	8565957	Cap, End
17	8566032	8565954	Cap, End
18	W10284557		Valve, Water Inlet W/Thermistor And Vacuum Break
19	8312709		Clip-Console
20	8318046		Clip, Capacitor
21	8566022		Knob, Timer
22	8566018		Dial,
23	8565944		Knob, Control
24	8536939		Clip, Knob
25	3347868	W10339879	Tie, Cable
26	8577378		U-Bend, Drain Hose
27	694419		Mini-Buzzer
28	8572717		Capacitor, Motor Start
29	8519200		Support, Rear Panel
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	8541668		Clamp, Hose
34	W10184148		Switch, Water Temperature
35	3950356		Switch, Rotary
36	3400818		Screw, Timer Mounting
37	W10163674		Switch, Rotary
38	62863	3390631	Screw, 10-16 X 3/8
39	W10244047		Panel, Console
40	W10248265		Harness, Wiring
41	8578411		Circuit Board, Agitation Delay
42	W10000080	8282566	Clip, Pine Tree
43	9740848		Screw, Mixing Valve Mounting

