


# Whirlpool 7MWT98960WM1 03 - AGITATOR, BASKET AND TUB PARTS



W10260920

5

Whirlpool [Residential Whirlpool 7MWT98960WM1 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8528278</a>			Dispenser, Fabric Softener
2	<a href="#">358237</a>			Screw And Washer
3	<a href="#">3949550</a>			Washer
4	<a href="#">3947517</a>			Agitator
5	8528150	<a href="#">W10445870</a>		Ring-Tub
6	<a href="#">3976308</a>			Gasket, Tub Ring
7	<a href="#">3354845</a>			Clip, Agitator
8	<a href="#">8543666</a>			Washer, Agitator
9	<a href="#">8537433</a>			Cam, Driven
10	3366877	<a href="#">80040</a>		Dog-Agitator
11	<a href="#">8055141</a>			Bearing-Driven Cam
12	<a href="#">W10116602</a>			Nut, Spanner
13	<a href="#">W10006327</a>			Basket And Balance Ring
14	<a href="#">2219077</a>			Clip, Pressure Switch Hose
15	<a href="#">W10006326</a>			Balance Ring
16	<a href="#">63849</a>			Strain Relief, Power Cord

17	<a href="#">389140</a>		Tub Block, Basket Drive
18	<a href="#">383727</a>		Gasket, Centerpodt
19	3347780	<a href="#">353244</a>	Hose, Pressure Switch
20	<a href="#">8538246</a>		Agitator
21	<a href="#">3946996</a>		Auger, Agitator
22	<a href="#">8577198</a>		Filter, Lint
23	<a href="#">8533540</a>		Retainer, Spring
24	<a href="#">3946997</a>		Spring, Compression

