


# Whirlpool 7MWT98965WW1 01 - TOP AND CABINET PARTS



Whirlpool Residential Whirlpool 7MWT98965WW1 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10155455		Not Available	Installation Instructions
"	W10213638		Not Available	Use & Care Guide
"	W10245375		Not Available	Feature Sheet
"	W10245230		Not Available	Energy Guide (Mexico)
"	W10213426		Not Available	Wiring Diagram
2	<a href="#">W10203530</a>			Top
3	62750			Spacer, Cabinet To Top (4)
4	<a href="#">W10192089</a>			Dispenser, Bleach
5	<a href="#">63424</a>			Cabinet
6	<a href="#">62780</a>			Clip, Top And Cabinet And Rear Panel
7	<a href="#">W10208782</a>			Spring-Extension, Glass Lid
8	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting
9	8533959	<a href="#">680762</a>		Nut
10	<a href="#">3350828</a>			Clip-Cylinder Retainer
11	<a href="#">8318084</a>			Switch, Lid

12	<a href="#">W10119828</a>		Screw, Lid Hinge Mounting
13	8559336	<a href="#">W10225136</a>	Hinge 7 Pad Assembly
14	<a href="#">W10202542</a>		Hinge, Lid
15	<a href="#">W10164516</a>		Lid Assembly
16	<a href="#">8319539</a>		Bearing, Lid Hinge
17	<a href="#">W10165554</a>		Screw, 10-16 X 3/8

