


# Whirlpool 7MWT99940VW1 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 7MWT99940VW1 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	<a href="#">16123</a>		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	W10194210	<a href="#">89503</a>		Hose-Inlet
"	W10196191	<a href="#">89503</a>		Hose-Inlet
3	<a href="#">8055003</a>			Clip, Harness And Pressure Switch
4	<a href="#">3400073</a>			Screw, Ground
5	<a href="#">8568314</a>			Strap, Console
6	<a href="#">W10194451</a>			Panel, Rear
7	<a href="#">62747</a>			Pad, Rear Panel
8	<a href="#">W10189267</a>			Drain Hose Assembly
9	<a href="#">8577787</a>			Timer, Control
10	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting
11	<a href="#">90767</a>			Screw, 8A X 3/8 HeX Washer Head Tapping
12	W10177243	<a href="#">W10339331</a>		Switch-WL

13	<a href="#">8566003</a>		Bracket, Control
14	<a href="#">W10115689</a>		Cord, Power
15	3952821	<a href="#">285777</a>	Relief-Str
16	8566035	<a href="#">8565957</a>	Cap, End
"	<a href="#">W10205959</a>		Cap, End
17	8566032	<a href="#">8565954</a>	Cap, End
"	<a href="#">W10205953</a>		Cap, End
18	<a href="#">W10175893</a>		Valve, Water Inlet
19	<a href="#">8312709</a>		Clip-Console
20	<a href="#">W10185367</a>		Clamp, Hose
21	<a href="#">W10232966</a>		Hose, Valve To Tub Ring
22	W10117298	<a href="#">596669</a>	Clamp, Manifold
23	3347868	<a href="#">W10339879</a>	Tie, Cable
24	<a href="#">8577378</a>		U-Bend, Drain Hose
25	<a href="#">W10274310</a>		Shield, Suds
26	<a href="#">9740848</a>		Screw, Mixing Valve Mounting
27	<a href="#">8519200</a>		Support, Rear Panel
28	3363366	<a href="#">616099</a>	Clamp
29	8317496	<a href="#">285655</a>	Clamp, Hose
30	3951449	<a href="#">285871</a>	Hose
31	<a href="#">8541668</a>		Clamp, Hose
32	<a href="#">W10184148</a>		Switch, Water Temperature
33	62863	<a href="#">3390631</a>	Screw, 10-16 X 3/8
34	<a href="#">3400818</a>		Screw, Timer Mounting
35	<a href="#">3950356</a>		Switch, Rotary
36	<a href="#">W10163674</a>		Switch, Rotary
37	<a href="#">W10209247</a>		Panel, Console
38	<a href="#">694419</a>		Mini-Buzzer
39	<a href="#">W10214752</a>		Harness, Wiring
40	<a href="#">8578411</a>		Circuit Board, Agitation Delay
41	<a href="#">8536939</a>		Clip, Knob
42	<a href="#">W10034730</a>		Knob, Timer
43	<a href="#">8566018</a>		Dial,
44	<a href="#">W10034380</a>		Knob, Control

