


Whirlpool 7MWTW9216YM0 03 - AGITATOR, BASKET AND TUB PARTS



Whirlpool [Residential Whirlpool 7MWTW9216YM0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|---------------------------|--------|-----------------------------|
| 1 | 8580006 | | | Dispenser, Fabric Softener |
| 2 | 358237 | | | Screw And Washer |
| 3 | 8054468 | | | Auger, Agitator |
| 4 | 8578209 | | | Agitator, Complete Assembly |
| 5 | 8528150 | W10445870 | | Ring-Tub |
| 6 | 3976308 | | | Gasket, Tub Ring |
| 7 | 3354845 | | | Clip, Agitator |
| 8 | 8543666 | | | Washer, Agitator |
| 9 | 8537434 | | | Cam, Driven |
| 10 | 3366877 | 80040 | | Dog-Agitator |
| 11 | 8055141 | | | Bearing-Driven Cam |
| 12 | 21366 | | | Nut, Spanner |
| 13 | W10389328 | | | Clothes Container, Assembly |
| 14 | 2219077 | | | Clip, Pressure Switch Hose |
| 15 | 387240 | | | Ring, Balance |
| 16 | 63849 | | | Strain Relief, Power Cord |

| | | | |
|----|---------------------------|---------------------------|-----------------------------|
| 17 | 389140 | | Tub Block, Basket Drive |
| 18 | 383727 | | Gasket, Centerpod |
| 19 | 3347780 | 353244 | Hose, Pressure Switch |
| 20 | 8578210 | | Agitator, Complete Assembly |
| 21 | 3949550 | | Washer |
| 22 | 8055228 | | Spacer, Thrust |
| 23 | 3354733 | W10074580 | Cap, Barrier |
| 24 | W10072840 | | Fabric Softener |
| 25 | 8533540 | | Retainer, Spring |
| 26 | 8055140 | | Spring, Compression |
| 27 | 8577198 | | Filter, Lint |

Howes
the laundry company®

Howes
the laundry company®

Howes
the laundry company®