


Whirlpool 8TLSR7432LT1 02 - CONTROLS AND REAR PANEL PARTS



W10112693

3

Whirlpool [Residential Whirlpool 8TLSR7432LT1 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	3400073			Screw, Ground
3	8571377	89503		Hose-Inlet
"	8571378	89503		Hose-Inlet
4	9740848			Screw, Mixing Valve Mounting
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	8559373	W10096921		Drain Hose Assembly
9	8541393			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	3366849	W10339228		Switch-WL

13	3948608		Bracket, Control
14	8559419		Cord, Power
15	8559337	285777	Relief-Str
16	8271368	279965	Endcap
17	357021	8572717	Capacitor, Motor Start
18	3952164	285805	Valve-Inlet
19	8577378		U-Bend, Drain Hose
20	8318046		Clip, Capacitor
21	301958	596669	Clamp, Manifold
22	8541607	3357328	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	303294	3367669	Protector, Edge
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	8541668		Clamp, Hose
29	3347868	W10339879	Tie, Cable
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	8055003		Clip, Harness And Pressure Switch
35	661612	W10168256	Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	8541669		Bucket, Drain Hose
38	8541658		Bucket, Drain Hose
39	8539607		Panel, Console
40	3363920	3363920A	Adapter
41	285655		Clamp, Hose
42	8577375		Coupling, Drain Hose
44	3957822		Knob, Timer
45	3957850		Dial, Timer
46	3957797		Knob, Push-To-Start
47	8536939		Clip, Knob
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8271362	279965	Endcap
52	8539874		Shield, Suds
53	3956652		Wiring Harness

the laundry company[®]