


# Whirlpool CEDC392PQ0 02 - CABINET PARTS



Whirlpool [Residential Whirlpool CEDC392PQ0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
2	347812	<a href="#">280048</a>		Panel-Rear
3	<a href="#">348726</a>			Base Assembly
4	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
5	8538265	<a href="#">8539558</a>		Motor-Drive
6	697776	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
7	<a href="#">696541</a>			Bracket, Motor
8	<a href="#">8066084</a>			Bushing, Snap
9	<a href="#">691366</a>			Idler And Pulley Assembly
10	<a href="#">3390631</a>			Screw, 10-16 X 3/8
12	<a href="#">8066051</a>			Pulley, Motor
15	8066064	<a href="#">3394652</a>		Belt, Drive
16	<a href="#">348705</a>			Panel, Side
18	3406104	<a href="#">3406105</a>		Door Switch Assembly
19	697773	<a href="#">3395530</a>		Screw
20	693943	<a href="#">280044</a>		Panel

21	685203	<a href="#">279220</a>	Clip
22	8066123	<a href="#">279264</a>	Air Channel Box
23	<a href="#">345670</a>		Lock, Top
24	<a href="#">3389441</a>		Door Catch Assembly
25	<a href="#">348023</a>		Hinge And Pin Assembly
26	696144	<a href="#">279570</a>	Latch
27	<a href="#">3390734</a>		Seal, Door
28	<a href="#">694091</a>		Trim, Side Right Hand
29	695656	<a href="#">280077</a>	Door
30	<a href="#">348205</a>		Door, Front
31	<a href="#">8562105</a>		Handle, Door
32	660719	<a href="#">279127</a>	Caster
33	20063371	<a href="#">279440</a>	Cord-Power
34	<a href="#">3394083</a>		Clip, Front Panel
35	<a href="#">345790</a>		Bracket, Power Cord
36	<a href="#">98234</a>		Clip, U-Bend

