


# Whirlpool CEDX631VQ1 02 - CABINET PARTS



W10253698

3

Whirlpool [Residential Whirlpool CEDX631VQ1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3404413</a>			Plug, Hinge Hole
2	3393008	<a href="#">308685</a>		Side Trim )
3	<a href="#">8541400</a>			Bracket, Cabinet
4	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
5	<a href="#">3396795</a>			Cover, Terminal Block
6	<a href="#">691366</a>			Idler And Pulley Assembly
7	3396807	<a href="#">280040</a>		Panel-Rear
8	342055	<a href="#">488627</a>		Screw
9	<a href="#">W10121316</a>			Plug, Multivent
10	3406104	<a href="#">3406105</a>		Door Switch Assembly
11	697773	<a href="#">3395530</a>		Screw
12	W10131364	<a href="#">341241</a>		Belt
13	<a href="#">693995</a>			Screw, Hex Head
14	<a href="#">348780</a>			Base, Motor
15	<a href="#">3400500</a>			Bolt, 3405245 5/16-18 X 3/4
16	3392100	<a href="#">49621</a>		Feet-Leveling

17	<a href="#">8066184</a>		Pulley, Motor
18	8530603	<a href="#">8533643</a>	Cabinet
19	<a href="#">98234</a>		Clip, U-Bend
20	690363	<a href="#">18776</a>	Lock, Front Top
21	3403571	<a href="#">279844</a>	Panel
22	W10194250	<a href="#">279827</a>	Motor-Drve
23	685203	<a href="#">279220</a>	Clip
24	690081	<a href="#">279570</a>	Latch
25	<a href="#">3404162</a>		Clamp, Motor
26	<a href="#">3405245</a>		5/16-18 X 3/4
27	697776	<a href="#">4331106</a>	Screw, No.10-32 X 7/16
28	3405514	<a href="#">W10362431</a>	Hinge And Pin Assembly
29	<a href="#">3394083</a>		Clip, Front Panel
30	<a href="#">279318</a>		Terminal Tinned And Brass Panel
31	696144	<a href="#">279570</a>	Latch
32	<a href="#">3403371</a>		Door, Inner
33	<a href="#">3403361</a>		Door Front
34	<a href="#">3405184</a>		Handle, Door
35	8066124	<a href="#">279264</a>	Air Channel Box
36	<a href="#">279393</a>		Terminal Block Screw Kit
37	<a href="#">3397659</a>		Block, Terminal
38	<a href="#">8066217</a>		Hinge, Top

