


Whirlpool ETW4200SQ0 03 - AGITATOR, BASKET AND TUB PARTS



8181380

5

Whirlpool Residential Whirlpool ETW4200SQ0 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3352483			Cap, Agitator
2	3949550			Washer
3	358237			Screw And Washer
4	63377			Agitator
5	8528150	W10445870		Ring-Tub
6	3976308			Gasket, Tub Ring
7	21366			Nut, Spanner
8	8526017	W10389329		Clothes Container, Assembly
9	8519788	387240		Ring, Balance
10	63849			Strain Relief, Power Cord
11	389140			Tub Block, Basket Drive
12	383727			Gasket, Centerpod
13	3347780	353244		Hose, Pressure Switch
14	2219077			Clip, Pressure Switch Hose