


# Whirlpool ETW4400TQ1 03 - AGITATOR, BASKET AND TUB PARTS



Whirlpool Residential Whirlpool ETW4400TQ1 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8565983</a>			Cap And Seal Assembly
2	<a href="#">3360824</a>			Auger, Agitator
3	<a href="#">3949550</a>			Washer
4	<a href="#">358237</a>			Screw And Washer
5	<a href="#">W10093671</a>			Agitator
6	8528150	<a href="#">W10445870</a>		Ring-Tub
7	<a href="#">3976308</a>			Gasket, Tub Ring
8	<a href="#">21366</a>			Nut, Spanner
9	<a href="#">W10042080</a>			Basket And Balance Ring
10	W10116964		Not Available	Balance Ring
11	<a href="#">63849</a>			Strain Relief, Power Cord
12	<a href="#">3363661</a>			Bearing, Driven Cam
13	<a href="#">389140</a>			Tub Block, Basket Drive
14	<a href="#">383727</a>			Gasket, Centerpodt
15	3347780	<a href="#">353244</a>		Hose, Pressure Switch
16	<a href="#">2219077</a>			Clip, Pressure Switch Hose

17	3363662	<a href="#">285748</a>	Cam-Agitator
18	3366877	<a href="#">80040</a>	Dog-Agitator
19	<a href="#">W10093670</a>		Agitator
20	3350389	<a href="#">285587</a>	Washer
21	<a href="#">W10112540</a>		Screw, Balance Ring
22	<a href="#">W10112537</a>		Screw, Adapter Assembly
23	<a href="#">358912</a>		Seal, Agitator Cap

