


Whirlpool ETW4400VQ3 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool Residential Whirlpool ETW4400VQ3 Washer Parts Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10211259			Harness, Wiring
2	9740848			Screw, Mixing Valve Mounting
3	3347868	W10339879		Tie, Cable
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	W10194450			Panel, Rear
7	62747			Pad, Rear Panel
8	W10189267			Drain Hose Assembly
9	W10199989			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577845	W10339334		Switch-WL
13	3948608			Bracket, Control
14	8578842	285800		Cord-Power

15	3952821	285777	Relief-Str
16	8274437	279960	Endcap
17	8274434	279960	Endcap
18	W10140917		Valve, Water Inlet W/Bi-Metal And Vacuum Break
19	8541668		Clamp, Hose
20	62863	3390631	Screw, 10-16 X 3/8
21	8538949		Knob, Timer
22	8538955		Dial, Timer
23	8538957		Knob, Control
24	8536939		Clip, Knob
25	8318046		Clip, Capacitor
26	8519200		Support, Rear Panel
27	W10000080	8282566	Clip, Pine Tree
28	8055003		Clip, Harness And Pressure Switch
29	8572717		Capacitor, Motor Start
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3400073		Screw, Ground
34	W10200863		Panel, Console
35	8578337		Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	388326		Screw, 8-18 X 1.25

the laundry company®

the laundry company®