


# Whirlpool GEQ8821LW1 02 - CABINET PARTS



8180007

3

Whirlpool [Residential Whirlpool GEQ8821LW1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
3	697776	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
4	<a href="#">3397659</a>			Block, Terminal
5	3394881	<a href="#">279782</a>		Switch-Lid
6	<a href="#">3398948</a>			Wire, Jumper
7	<a href="#">8310656</a>			Cabinet
"	8528155	<a href="#">3979259</a>		Cabinet
8	3392100	<a href="#">49621</a>		Feet-Leveling
"	<a href="#">279810</a>			Foot-Optional
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	697750	<a href="#">W10470674</a>		Dryer Exhaust Kit
"	<a href="#">3979261</a>			Plug, Multivent
13	3388672	<a href="#">279640</a>		Pulley-Idr
14	<a href="#">279318</a>			Terminal Tinned And Brass Panel

15	3390647	<a href="#">488729</a>	Screw
16	<a href="#">3394081</a>		Wire, Broken Belt Switch
18	<a href="#">233520</a>		Washer, Thrust
19	<a href="#">297092</a>		Clip
20	<a href="#">690997</a>		Washer, Thrust
21	<a href="#">3387560</a>		Hinge, Door
"	<a href="#">3387559</a>		Hinge, Door
22	<a href="#">3387565</a>		Spring, Door
23	<a href="#">8066120</a>		Lever, Door Switch
24	<a href="#">3394331</a>		Plate Cover
25	<a href="#">3395532</a>		Exhaust Pipe And Bracket
26	<a href="#">3393657</a>		Restrainer, Belt
27	8538263	<a href="#">279787</a>	Motor-Drve
28	<a href="#">49026</a>		4" - 90° Elbow
29	<a href="#">3389729</a>		Pulley, Motor
30	3387610	<a href="#">661570</a>	Belt
31	<a href="#">3388600</a>		Clip, Lint Duct
32	<a href="#">3387118</a>		Bracket, Motor
33	<a href="#">279393</a>		Terminal Block Screw Kit
34	<a href="#">98129</a>		Screw, 6-20 X 1 1/16
35	<a href="#">3395534</a>		Exhaust Pipe
36	697773	<a href="#">3395530</a>	Screw
37	3395535	<a href="#">8563749</a>	Exhaust Pipe
38	3390663	<a href="#">681414</a>	Screw, 10AB X 1/2
39	3388674	<a href="#">W10118756</a>	Idler Bracket
40	3357011	<a href="#">308685</a>	Side Trim )
41	<a href="#">3406107</a>		Door Switch Assembly
44	<a href="#">3387242</a>		Seal, Front Panel
46	<a href="#">3388229</a>		Retainer, Toe Panel
47	697655	<a href="#">280079</a>	Door
48	<a href="#">694091</a>		Trim, Side Right Hand
49	<a href="#">8521938</a>		Door, Front
"	<a href="#">8521936</a>		Door, Front
51	697227	<a href="#">279659</a>	Panel
"	3979198	<a href="#">279972</a>	Panel
52	696144	<a href="#">279570</a>	Latch
54	3393008	<a href="#">308685</a>	Side Trim )
57	3390736	<a href="#">3390732</a>	Seal-Door
58	690081	<a href="#">279570</a>	Latch
60	<a href="#">3979727</a>		Handle, Door
61	697215	<a href="#">3406797</a>	Toe Panel
"	3979197	<a href="#">3979260</a>	Toe Panel
62	279818	<a href="#">W10470674</a>	Dryer Exhaust Kit
"	279969	<a href="#">W10470674</a>	Dryer Exhaust Kit