


Whirlpool GGW9200LQ1 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Models: GGW9200LW1, GGW9200LQ1, GGW9200LL1, GGW9200LT1
(White/Platinum) (White/Blue) (Pewter) (Biscuit)

GAS DRYER



05-03 Printed in U.S.A. (djc)

1

Part No. 8180004 Rev. A

Whirlpool Residential Whirlpool GGW9200LQ1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT8542742		Not Available	Literature Parts (Use & Care Guide)
"	LIT8541834		Not Available	Literature Parts (Tech Sheet)
2	8519251	W10117263		Top
"	3980096	3980357		Top
"	8519252	3979307		Top
3	8299950			Harness, Main
4	8530587			Panel, Console
"	8530588			Panel, Console
"	3980188			Panel, Console
"	3979788		Not Available	Panel, Console (Biscuit)
5	3394427			Clip-Harness
6	8519271			Bracket, Console
7	353424			Plug, Terminal
8	94614			Terminal
9	3936144			Do-It-Yourself Repair Manuals
10	94613	596797		Terminal

11	3390647	488729	Screw
12	488886	488787	Screw
13	8519406		Bezel, Cycle
14	3936150		Connector, 7-Circuit
15	3395683		Receptacle, Multi-Terminal
16	8281225		Screw, 8-18 X 1/2
17	2203186		Connector, 5-Circuit
18	46197020472	8181859	Knob, Control
"	46197020471	8181881	Knob, Control
"	46197020742	8182050	Knob, Control
"	46197020741	8182049	Knob, Control
19	8530589		User Interface
"	8530590		User Interface
"	3980189		User Interface
"	3979789		User Interface
20	8530591		Button, Start
21	8530592		Button, Pause/Cancel

