


Whirlpool GGW9250PL0 02 - CABINET PARTS



8180499

3

Whirlpool [Residential Whirlpool GGW9250PL0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8317340			Cover, Terminal Block
2	3390814	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	697776	4331106		Screw, No.10-32 X 7/16
4	8519213	W10131287		Panel
"	8519217	3980359		Panel
"	8519214	W10131288		Panel
5	3394881	279782		Switch-Lid
6	8521959	W10121663		Dryer Rack
7	8519209	W10131287		Panel
"	8519216	3980358		Panel
"	8519210	W10131288		Panel
8	3392100	49621		Feet-Leveling
"	279810			Foot-Optional
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler

11	3389420		Retainer-Idler 1/4-20 X 1/16
12	697750	W10470674	Dryer Exhaust Kit
"	3979261		Plug, Multivalent
"	3388311		Plug, Multivalent
13	3388672	279640	Pulley-Idr
14	3978776		Bracket, Gas Pipe Switch
15	8066120		Lever, Door Switch
16	3394081		Wire, Broken Belt Switch
17	8564132	8564134	Board, Sound Dampening
18	233520		Washer, Thrust
19	8283288		Wire, Jumper
20	690997		Washer, Thrust
21	8066115	3394331	Plate Cover
22	8529053		Ramp, Door Door Switch
23	8521961		Support, Dry Rack
24	693995		Screw, Hex Head
25	8521957	W10121663	Dryer Rack
26	3393657		Restrainer, Belt
27	8538263	279787	Motor-Drve
28	3398948		Wire, Jumper
29	3389729		Pulley, Motor
30	3387610	661570	Belt
31	8529757		Bracket, Burner
32	3387118		Bracket, Motor
33	3401401	3401402	Cord, Power
34	49026		4" - 90° Elbow
36	3395532		Exhaust Pipe And Bracket
37	3395534		Exhaust Pipe
38	3395535	8563749	Exhaust Pipe
39	3388674	W10118756	Idler Bracket
41	8519323	8283288	Wire, Jumper
42	98129		Screw, 6-20 X 1 1/16
43	3390647	488729	Screw
44	3387242		Seal, Front Panel
45	3393008	308685	Side Trim)
46	8519459		Clip, Toe Panel
50	8519207		Base, Cabinet
51	8562167	280096	Panel
"	8562169	280098	Panel
"	8562168	280097	Panel
52	696144	279570	Latch
55	8299929		Harness, Digital Interface
56	8519273	W10119274	Bracket, Control
57	8546219		Control Board
59	3400826		Screw, 8-18 X 3/4
61	8519233		Toe, Panel
"	3980095		Toe, Panel
"	8519234		Toe, Panel
62	8519219	280036	Panel-Rear
63	692400		Nut, Push-In
64	343641	681414	Screw, 10AB X 1/2
"	BLANK	Not Available	Optional Parts Not Included
66	279818	W10470674	Dryer Exhaust Kit

" 279969

[W10470674](#)

Dryer Exhaust Kit

" 279925

[W10470674](#)

Dryer Exhaust Kit

