


Whirlpool GGW9250PT0 05 - DOOR PARTS



8180499

9

Whirlpool [Residential Whirlpool GGW9250PT0 Dryer Parts](#) Parts Diagram 05 - DOOR PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8563855			Label, Hinge Hole
2	8559709	280200		Hinge
3	342043	486146		Screw
4	9742177			Screw, 8-18 X .625
5	8529539			Bracket, Handle
7	8559739			Handle, Door Assembly
"	8559743			Handle, Door Assembly
"	8559741			Handle, Door Assembly
"	8559738			Handle, Door Assembly Handle, Door Assembly
"	8559742			Handle, Door Assembly Handle, Door Assembly
"	8559740			Handle, Door Assembly Handle, Door Assembly
8	3357011	308685		Side Trim)
9	8541574	8572960		Door Assembly
"	3980079	8572962		Door Assembly

"	3977873	8572961	Door Assembly
10	8546200	8557501	Inner Door Assembly
11	355515		Screw, 8-18 X 11/16
12	3389441		Door Catch Assembly
14	8529540	8303811	Badge, Assembly
15	8528289		Filler Handle
"	3980082		Filler Handle
"	3979771		Filler Handle)
"	8528287		Filler Handle Filler Handle
"	3980101		Filler Handle Filler Handle
"	3979772		Filler Handle Filler Handle
16	8559713		Cover-Hinge, Stationary
"	8559719		Cover-Hinge, Stationary
"	8559717		Cover-Hinge, Stationary
"	8559712		Cover-Hinge, Stationary Cover-Hinge, Stationary
"	8559718	Not Available	Cover-Hinge, Stationary (RH) (Following Parts Not Included) Cover-Hinge, Stationary (LH) (Pewter)
"	8559716		Cover-Hinge, Stationary Cover-Hinge, Stationary
17	8559722		Cover-Hinge, Rotating
"	8559724		Cover-Hinge, Rotating
"	8559723		Cover-Hinge, Rotating
18	8547091	8181929	Clip, Trim
19	8558683	8533767	Trim And Clip Assembly
"	8558685	8533769	Trim And Clip Assembly
"	8558684	Not Available	Trim & Clip Assembly (Lower) (Biscuit)
20	8558687	8529526	Trim And Clip Assembly
"	8558692	3980088	Trim And Clip Assembly
"	8558690	3979783	Trim And Clip Assembly
21	8558689	8529528	Trim And Clip Assembly
"	8558693	3980090	Trim And Clip Assembly
"	8558691	3979784	Trim And Clip Assembly

