


Whirlpool GGW9250PW3 05 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)



8181216

9

Whirlpool [Residential Whirlpool GGW9250PW3 Dryer Parts](#) Parts Diagram 05 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|-------------------------|--------|--|
| 1 | 8066209 | 8563855 | | Label, Hinge Hole |
| 2 | 8559709 | 280200 | | Hinge |
| 3 | 8534015 | 280203 | | Screw-Kit |
| 4 | 9742177 | | | Screw, 8-18 X .625 |
| 5 | 8529539 | | | Bracket, Handle |
| 7 | 8559739 | | | Handle, Door Assembly |
| " | 8559743 | | | Handle, Door Assembly |
| " | 8559741 | | | Handle, Door Assembly |
| " | 8559738 | | | Handle, Door Assembly Handle, Door Assembly |
| " | 8559742 | | | Handle, Door Assembly Handle, Door Assembly |
| " | 8559740 | | | Handle, Door Assembly Handle, Door Assembly |
| 8 | 3357011 | 308685 | | Side Trim) |
| 9 | 8572960 | | | Door Assembly |

| | | | |
|----|-------------------------|-------------------------|--|
| " | 8572962 | | Door Assembly |
| " | 8572961 | | Door Assembly |
| 10 | 8557501 | | Inner Door Assembly |
| 11 | 355515 | | Screw, 8-18 X 11/16 |
| 12 | 3389441 | | Door Catch Assembly |
| 14 | 8529540 | 8303811 | Badge, Assembly |
| 15 | 8528289 | | Filler Handle |
| " | 3980082 | | Filler Handle |
| " | 3979771 | | Filler Handle) |
| " | 8528287 | | Filler Handle Filler Handle |
| " | 3980101 | | Filler Handle Filler Handle |
| " | 3979772 | | Filler Handle Filler Handle |
| 16 | 8559713 | | Cover-Hinge, Stationary |
| " | 8559719 | | Cover-Hinge, Stationary |
| " | 8559717 | | Cover-Hinge, Stationary |
| " | 8559712 | | Cover-Hinge, Stationary Cover-Hinge, Stationary |
| " | 8559718 | Not Available | Cover-Hinge, Stationary (RH) (Following Parts Not Included) Cover-Hinge, Stationary (LH) (Pewter) |
| " | 8559716 | | Cover-Hinge, Stationary Cover-Hinge, Stationary |
| 17 | 8559722 | | Cover-Hinge, Rotating |
| " | 8559724 | | Cover-Hinge, Rotating |
| " | 8559723 | | Cover-Hinge, Rotating |
| 18 | 8547091 | 8181929 | Clip, Trim |
| 19 | 8558683 | 8533767 | Trim And Clip Assembly |
| " | 8558685 | 8533769 | Trim And Clip Assembly |
| " | 8558684 | Not Available | Trim & Clip Assembly (Lower) (Biscuit) |
| 20 | 8558687 | 8529526 | Trim And Clip Assembly |
| " | 8558692 | 3980088 | Trim And Clip Assembly |
| " | 8558690 | 3979783 | Trim And Clip Assembly |
| 21 | 8558689 | 8529528 | Trim And Clip Assembly |
| " | 8558693 | 3980090 | Trim And Clip Assembly |
| " | 8558691 | 3979784 | Trim And Clip Assembly |
| " | 72017 | | Paint, Touch-Up |
| " | 4396174 | | Paint, Touch-Up |
| " | 4392899 | | Paint, Touch-Up |
| " | 350930 | | Paint, Pressurized Spray B |
| " | 4396175 | | Paint, Pressurized Spray |
| " | 4392901 | | Paint, Pressurized Spray |
| " | 350938 | | Paint, Pressurized Spray B |
| " | 799344 | | Paint, Touch-Up) |
| " | 4392900 | | Paint, Bulk) |
| " | BLANK | Not Available | ACCESSORY PARTS |
| " | 8529894 | 346764 | Kit, Hold Down |
| " | 8530070 | | Kit, Door Reversing |
| " | 8530072 | | Kit, Door Reversing |
| " | 8530071 | | Kit, Door Reversing |
| " | 8541503 | | Kit, Stack Assembly |
| " | 80047 | | PAINT, BULK (1 QT.) (KIT, DRYER REPAIR) |