


Whirlpool GGW9868KL4 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Models: GGW9868KQ4, GGW9868KL4, GGW9868KT4
(Designer White) (Pewter) (Biscuit)

27" GAS DRYER



6-05 Litho in U.S.A. (LT)

1

Part No. 8180708

Whirlpool Residential Whirlpool GGW9868KL4 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8528148		Not Available	Guide, Use & Care
"	3979174		Not Available	Instructions, Installation
"	8541837		Not Available	Tech Sheet
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	677818		Not Available	Manual, Do-It- Yourself Repair (Dryer)
2	8274338	285906		Panel-Rear
3	8566150			Control Board
4	8568314			Strap, Console
5	304231			Screw, 8-18 X 1/2
6	3978825			Panel, Console
"	3978826			Panel, Console
7	3395683			Receptacle, Multi-Terminal
8	8299686			Cap, End
"	8299688			Cap, End

"	8299687		Cap, End
9	8299690		Bracket, Control
10	8316751		Medallion Insert
11	3401850		Harness-Gas
12	3400073		Screw, Ground
13	3400826		Screw, 8-18 X 3/4
14	3391018		Tie Cable
15	693995		Screw, Hex Head
16	353424		Plug, Terminal
17	717252		Receptacle, Terminal
18	3403499		Connector, 2-Postion
19	8299949		Harness, Wiring
20	357213		Nut, Push-In
21	3978832	3979256	Top
"	3978837	3979257	Top
"	3978833	3979258	Top
22	8299683	Not Available	Cap, End (L.H.) (Includes Item 13) (White)
"	8299685		Cap, End
"	8299684		Cap, End
23	3936144		Do-It-Yourself Repair Manuals
24	3403498		Connector, 3-Position
26	2203186		Connector, 5-Circuit
27	3936150		Connector, 7-Circuit
28	3394427		Clip-Harness
29	94614		Terminal
30	8521943		Medallion Assembly
"	8521944		Medallion Assembly
31	3406653		Harness, Sensor
32	8317340		Cover, Terminal Block
33	3390814	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
34	8312709		Clip-Console

